

FEMA Benefit-Cost Analysis (BCA) Toolkit

Version 6.0

User Guide

May 2019



Contents

Using this Guide	5
BCA Toolkit 6.0: User Interface Overview	6
Platform	6
System Requirements	6
Installation	6
Launching	7
Home Screen	8
Project Configuration Screen	9
Hazard Analysis Screen	10
Cards	10
Default Yes/No Toggles	11
Comment Boxes	12
Project Summary Screen	13
Help Content	14
Updates	16
Analysis Options	17
Structure Types	17
Critical Facilities and Hurricane Wind/Safe Rooms	17
Hazard Options	18
Analysis Methodology	19
“Full Data” Hazard Modules vs. Modeled Damages	20
Damage Frequency Assessment vs. Historic/Professional Estimated Damages	25
Navigating the Tool	28
Adding a Project	28
Adding Comments	31
Accessing the Help Content	35

Adding a Structure to a Project.....	39
Copying a Structure.....	40
Deleting a Structure	41
Viewing a Report.....	42
Printing/Saving the Report.....	43
Exporting a Project.....	45
Importing a Project	47
Deleting a Project.....	55
File Management	56
Saving the File	56
Saving in Excel Online	56
Organizing Projects	57
Version Control	57
Frequently Asked Questions	58
Getting Started.....	58
1. I'm having trouble installing/opening the Toolkit. Where can I get help?	58
2. Why can't I open the add-in in another Excel spreadsheet?	58
3. How can I learn more about FEMA's Benefit-Cost Analysis (BCA) process?.....	58
4. Why is my project grayed out when I open it?	58
General.....	59
5. What should I do if I'm unfamiliar with a term or concept?	59
6. Can I still use v.5.3.0 if I want?	59
7. Can I use the BCA Toolkit v.6.0 for a FEMA Public Assistance mitigation project?	59
8. Where is the Damage Frequency Assessment module?.....	59
9. Can I upload my documentation into the Toolkit?	60
10. Can I change a default value?	60
11. Can I import projects from v.5.3.0 into v.6.0?	60
12. How do I update the Toolkit?.....	60

13.	Why doesn't my BCR change when I change an input?.....	61
14.	What should I do if I find an error in the Toolkit?.....	61
	Structure, Hazard, Mitigation Action, and Damage Frequency Relationship Options	62
15.	Why are some hazards grayed out?.....	62
16.	How do I select a hazard that's grayed out?.....	62
17.	How do I do a BCA for a generator in v.6.0?	62
18.	How do I do a hurricane wind retrofit or a hurricane safe room for a critical facility?	62
	Reports.....	63
19.	How do I save or print my report?	63
20.	Why can't I print the report or export projects on a Mac?	63
	Appendix A: Installation Instructions.....	64
	Excel desktop (Non-FEMA machines)	64
	Excel desktop (FEMA machines)	64
	Excel Online.....	65

Using this Guide

This document contains an overview of the components and terms used in the Benefit-Cost Analysis (BCA) Toolkit Version 6.0, information on how to navigate the new Toolkit, and answers to common questions about the new Toolkit.

This document is not intended as a substitute for the E/L 0276: Introduction to Benefit-Cost Analysis course offered through the Emergency Management Institute (EMI). This document is designed to guide users who are familiar with FEMA's Benefit-Cost Analysis Toolkit v.5.3.0 through the components and terms used in v.6.0 and to provide an overview of the Toolkit's functions.

If you are not familiar with the concepts behind BCA, FEMA offers courses and training materials. More information is available at www.fema.gov/benefit-cost-analysis. If you have questions about any of the terms used in this document, please contact the Benefit-Cost Helpline at bchelpline@fema.dhs.gov.

BCA Toolkit 6.0: User Interface Overview

Platform

The BCA Toolkit 6.0 is built on a Microsoft Excel platform and uses an add-in to perform the BCA calculations. An add-in can be thought of as an “app” within Excel that extends the functionality of the program. The add-in only works in the official [BCA Toolkit 6.0 Excel template file](#).

System Requirements

Users must have Excel 2013 or later installed on their machine or may use Excel Online. (Please note that Macintosh users must have Excel 2016 or later as there was no Office 2013 release for Mac.) If using a FEMA machine, you must have Office 365.

To use Excel Online, your computer must be connected to the internet and you will need a Microsoft Office 365 account. See the “Excel Online” section in [Appendix A](#). Please also see the “[File Management](#)” section for important information about saving your project data in Excel Online.

Installation

See [Appendix A](#) of this document for installation instructions.

Launching

1. Launch the BCA Toolkit by clicking on the FEMA BCA V6.0 icon in the top ribbon under the Home tab. A sidebar entitled “FEMA Benefit-Cost Analysis Calculator” should appear on the righthand side of the screen as shown in Figure 1 (this may take a moment if launching for the first time). You may click through images on the sidebar for an overview of how to create a project and how to add a new structure or mitigation action to a project.
2. Click “Open Calculator” to begin your BCA. A new window will open. Click “Add Project” to begin a new BCA.
3. To save your work, click “Finish” on the second screen, and save the Excel file, renaming it if desired.




Figure 1: Launch screen of BCA Toolkit v.6.0

Home Screen

The Home screen (see Figure 2) is the main screen you will see after clicking the “Open Calculator” button on the launch screen. From here, you can begin a new project, edit or delete an existing project, and import or export projects. If you have previously saved projects in the Excel file, they will appear in the list here.

See the “Navigating the Toolkit” section of this guide for more information.




Figure 2: Home screen

Project Configuration Screen

The Project Configuration screen is the first step in beginning your BCA calculation. On this screen (see Figure 3) you will enter basic information about your project, such as your project title, location, property/structure type, and project costs. See the “Navigating the Toolkit” section of this guide for more information.

The screenshot displays the 'Project Configuration' window with a dark blue header. The main area contains several input fields and options:

- Project Title:** A text input field with the placeholder 'Enter Project Title'.
- Property Location:** A text input field with the placeholder 'Enter a location'.
- Use Property Location?:** A toggle switch currently set to 'Yes'.
- OR** (separator)
- Latitude/Longitude:** Two columns of input fields. The 'Latitude' column has a '5-digit Zip Code' field and a 'Select State' dropdown. The 'Longitude' column has a 'Select County' dropdown.
- Property Structure Type:** A dropdown menu with the placeholder 'Select Structure Type...'.
- Hazard Type:** A dropdown menu with the placeholder 'Select Hazard Type...'.
- Mitigation Action Type:** A dropdown menu with the placeholder 'Select Mitigation Action Type...'.
- Property Title:** A text input field with the placeholder 'Enter Property Title'.
- Frequency and Damage Relationship based on:** Three radio button options: 'Modeled Damages' (selected), 'Historical Damages', and 'Professional Expected Damages'.
- Use Decimal Degrees?:** A toggle switch currently set to 'Yes'.

Figure 3: Project Configuration screen

Hazard Analysis Screen

After clicking “Next” on the Project Configuration screen, the Toolkit will open the Hazard Analysis screen. The “cards” (see “Cards” section below) you see here are dependent upon the information you entered on the Project Configuration screen. For example, if you selected Critical Facility as the property type, you will see a card with inputs for critical facility type. In order to save your work, you **must** click “Finish” at the bottom of this screen and then save the Excel file.

Cards

The BCA Toolkit 6.0 data input sections are comprised of “cards.” As shown in Figure 4, these are the bounded boxes seen on both the Project Configuration and Hazard Analysis screens and may be thought of as different sections or categories of data inputs. As mentioned above, the cards you see on the Hazard Analysis screen are dependent upon the information you entered in the Project Configuration screen.

The screenshot displays two cards from the Hazard Analysis screen. The first card, titled "Hazard Probability Parameters - Flood", contains input fields for "Enter the Lowest Floor Elevation of the Property (ft):" and "Enter the Streambed Elevation at the Property Location (ft):", both set to 0. It also includes a section for "Enter below the Recurrence Interval, corresponding Water Surface Elevation, and Discharges:" with a toggle for "Use Default Recurrence Intervals?" set to "Yes". Below this is a table with three columns: "Recurrence Interval (years)", "Water Surface Elevation (ft)", and "Discharge (cfs)". The table has four rows for recurrence intervals of 10, 50, 100, and 500 years, all with values of 0. The second card, titled "Building Information", has a dropdown for "Select the Building Type" set to "Select Non-Residential Type..." and a toggle for "Is the Building Engineered?" set to "No".

Hazard Probability Parameters - Flood

Enter the Lowest Floor Elevation of the Property (ft): 0

Enter the Streambed Elevation at the Property Location (ft): 0

Enter below the Recurrence Interval, corresponding Water Surface Elevation, and Discharges:

Use Default Recurrence Intervals? ☒ Yes

BEFORE MITIGATION		
Recurrence Interval (years)	Water Surface Elevation (ft)	Discharge (cfs)
10	0	0
50	0	0
100	0	0
500	0	0

Building Information


Select the Building Type: Select Non-Residential Type...

Is the Building Engineered? ☒ No

Figure 4: Cards

Default Yes/No Toggles

One of the goals in developing Version 6.0 was to reduce the number of manual-input data fields. Where possible, default values have been populated in the Toolkit, with the option to switch the toggle to No and enter a custom value (see Figure 5).



The screenshot shows a web form titled "Standard Benefits - Building". It contains several input fields and calculated values. A red box highlights two "Use Default?" toggles, both of which are currently set to "Yes".

Field	Value	Use Default?
Select Damage Curve:	USACE Generic	
Enter Building Size (sq.ft):	2,400	
Building Replacement Value (\$/sq.ft):	100	Yes
Demolition Threshold (%):	50	Yes
Expected Annual Losses due to Building Damages Before Mitigation (\$):	4,163	
Expected Annual Losses due to Building Damages after Mitigation (\$):	0.00	
Expected Annual Benefits - Building (\$):	4,163	

Figure 5: Default Yes/No toggles

If a non-default value is used, users should enter a comment in the comment box (see below for more information) and include documentation with their Hazard Mitigation Assistance (HMA) project application. See the "Navigating the Toolkit" section of this guide for more information.

Comment Boxes

Comment boxes (see Figure 6) are available for any non-default value input or data field that is not automatically calculated. Comment boxes should be used as a way for the BCA analyst to tell the BCA reviewer why a certain value was used and to refer the reviewer to the appropriate documentation in the project application. See the “Navigating the Toolkit” section of this guide for more information.


The screenshot shows a web application interface for 'Hazard Probability Parameters'. A modal window titled 'Add justification for Lowest Floor Elevation' is open, featuring a large text area labeled 'comments' and a 'Save' button. A red rectangle highlights a menu icon (three horizontal lines with a plus sign) in the top right corner of the modal. In the background, the main form has input fields for 'Lowest Floor Elevation', 'Streambed Elevation (ft)', and 'Recurrence Interval'. Below these is a table with three columns: 'Recurrence Interval (years)', 'Water Surface Elevation (ft)', and 'Discharge (cfs)'. The table contains four rows of data with values 10, 50, 100, and 500 for the recurrence interval, and 0 for the other two columns.

Recurrence Interval (years)	Water Surface Elevation (ft)	Discharge (cfs)
10	0	0
50	0	0
100	0	0
500	0	0

Figure 6: Comment boxes

Project Summary Screen



Upon clicking “Finish” on the Hazard Analysis screen, you will see the Project Summary screen (see Figure 7). From here you can add/delete a structure to/from your project, copy a structure, or generate the project report. See the “Navigating the Toolkit” section of this guide for more information.

**FEMA**


Benefit-Cost Calculator
v6.0.0 (Build 20190402.2227)

Benefit-Cost Analysis
Project Name: Sample Project

[Home](#) [+ Add Mitigation Action](#) [Delete Mitigation Actions](#) [View Report](#)

SELECT	MAP MARKER	MITIGATION TITLE	PROPERTY TYPE	HAZARD	BENEFITS (B)	COSTS (C)	BCR (B/C)	COPY
<input checked="" type="checkbox"/>	1	Community @ 400 C St SW, Washington, DC 20024, USA		Tornado Safe Room	\$ 550,094	\$ 250,000	2.20	
Totals					\$ 550,094	\$ 250,000	2.20	

Map Satellite



Google Map data ©2019 Google Terms of Use Report a problem

Figure 7: Project Summary screen

Help Content

The Help Content in the BCA Toolkit may be accessed by clicking on the “i” icon at the top of each card as shown in Figure 8. The Help Content is dynamic, meaning that the information that appears will depend on which page of the toolkit you’re on and which card you clicked on.

Project Configuration

Project Title

Enter Project Title

Property Location

Enter a location

OR

Latitude

Latitude

Longitude

Longitude

5-digit Zip Code

Select State

Select County

Property Structure Type

Select Structure Type...

Hazard Type

Select Hazard Type...

Mitigation Action Type

Select Mitigation Action Type...

Property Title

Enter Property Title

Frequency and Damage Relationship based on:

Modeled Damages

Historical Damages

Professional Expected Damages

Use Property Location?

Yes

Use Decimal Degrees?

Yes

Figure 8: Help content icon

To close the Help content window, make sure you click the inner “x” as shown in Figure 9. Clicking on the other “x” will close the add-in window altogether.




Figure 9: Closing the Help content window

Updates

If updates are available, BCA Toolkit 6.0 will automatically update upon reopening if your computer is connected to the internet. You no longer need to manually install updates.

Release notes for any future updates may be found at www.fema.gov/benefit-cost-analysis.

Analysis Options

Structure Types

The structure type options in v.6.0 are Residential Structure, Non-Residential Structure, Critical Facility, Utilities, and Roads & Bridges. These are the same options as in v.5.3.0. The main difference is that users must now select their structure type on the first screen regardless of hazard and analysis methodology, instead of answering multiple questions so that the Toolkit can determine the structure type and appropriate analysis methodology.

Critical Facilities and Hurricane Wind/Safe Rooms

To do a BCA for a hurricane safe room for a critical facility, you must select “Non-Residential Building” as the structure type and then select “Hurricane Safe Room” as the hazard. This is because the benefits are based not on loss of service of the facility but on injury and loss of life of the people inside the safe room.

When conducting a BCA for a hurricane wind retrofit of a critical facility, there are two options for how to analyze the benefits. The appropriate choice depends on whether the project will primarily reduce (1) physical damages to the building or (2) loss of service. If the project primarily reduces physical damages and/or loss of function resulting from the physical damages, then the user should select Non-Residential Building for the structure type and use the modeled damages approach. If the project’s loss of service reduction is primarily based on reduced service down time instead of improved building performance, then the user should select “Critical Facility” as the structure type and use the Historical or Professional Expected Damages methodology.

Hazard Options

Hazards in v.5.3.0	Hazards in v.6.0
Flood	Riverine Flood
	Coastal A Flood
	Coastal V Flood
	Coastal Unknown Flood
Hurricane Wind	Hurricane Wind
Hurricane Safe Room	Hurricane Safe Room
Tornado Safe Room	Tornado Safe Room
Earthquake	Seismic
Wildfire	Wildfire
Drought	Drought
N/A	Landslide
	Dam/Levee Break
	Extreme Temperature
	Infrastructure Failure
	Severe Storm
	Tsunami
	Volcano
	Winter Storm
	Uncategorized

Table 1: Hazard Options in v.5.3.0 versus v.6.0

Version 6.0 keeps all the same hazards as v.5.3.0 and adds new hazards based on FEMA’s Data Governance Council standards (see Table 1). These new hazards must currently be analyzed using either the Historical or Professional Estimated Damages method, which are discussed further below.

Additionally, v.6.0 separates out coastal and riverine flooding. This does not change any of the calculations; the main difference between the various flood options is which Depth Damage Functions (DDFs) appear on the Hazard Analysis screen.

If your structure is along a tidal river but not impacted by wave action and you want to account for future relative sea level rise (SLR), you may select “Coastal Unknown” to select the applicable DDF and input your SLR information.

Version 5.3.0	Version 6.0
<ul style="list-style-type: none">• “Full Data” Hazard Modules• Damage Frequency Assessment	<ul style="list-style-type: none">• Modeled Damages• Historic Damages• Professional Estimated Damages

Figure 10: Analysis Methodology Differences between v.5.3.0 and v.6.0

None of the calculations or analysis methods have changed from v.5.3.0 to v.6.0. The same information is required for a drainage project or a hurricane wind retrofit regardless of which version of the Toolkit you use. The way these analysis types are configured within the Toolkit has changed, however.

The Damage Frequency Assessment (DFA) method is no longer a stand-alone module but is now contained within every hazard option as two separate analysis methods, based on the available data. The different methodologies, how to select or switch between them, the project options for each methodology, and the data needed for each are covered in the following sections.

“Full Data” Hazard Modules vs. Modeled Damages

What used to be known as the “full data” hazard modules (e.g. Long-Form Flood, Hurricane Wind, etc.) in previous iterations of the Toolkit are now consolidated as the “Modeled Damages” approach. The availability of this approach depends on the hazard and structure type selected. For example, the Modeled Damages approach is available for a residential structure acquisition in the riverine flood hazard but is not available for a utilities or road drainage project. A utilities-based drought mitigation project, however, could be completed using modeled damages.

All the project types that previously used the full data modules can be analyzed using the Modeled Damages approach. For residential structures, non-residential structures, and critical facilities, Modeled Damages is the default damage frequency approach. Figure 10, Figure 11, Figure 12, and Figure 13 on the following pages show which hazards are available for these structure types.

Home

Project Summary

Project Configuration

Project Title

Enter Project Title

Property Location

Enter a location

OR

Latitude

Longitude

Latitude

Longitude

5-digit Zip Code

Select State

Select County

Property Structure Type

Residential Building

Hazard Type

Select Hazard Type...

Mitigation Action Type

Select Mitigation Action Type...

Property Title

Enter Property Title

Frequency and Damage Relationship based on:

☒ Modeled Damages

☐ Historical Damages

☐ Professional Expected Damages

Cost Estimation

Enter the Project Useful Life:

0

Select Hazard Type...

Riverine Flood

Coastal A Flood

Coastal V Flood

Coastal Unknown Flood

Hurricane Wind

Hurricane Safe Room

Tornado Safe Room

Wildfire

Drought

Landslide

Seismic

Dam/Levee Break

Extreme Temperature

Infrastructure Failure

Severe Storm

Tsunami

Volcano

Winter Storm

Uncategorized

Figure 11: Hazards available for Residential Building using the Modeled Damages methodology

Home

Project Summary

Project Configuration

Project Title

Enter Project Title

Property Location

Enter a location

OR

Latitude

Longitude

Latitude

Longitude

5-digit Zip Code

Select State

Select County

Property Structure Type

Non-Residential Building

Hazard Type

Select Hazard Type...

Mitigation Action Type

Select Mitigation Action Type...

Property Title

Enter Property Title

Frequency and Damage Relationship based on:

☒ Modeled Damages

☐ Historical Damages

☐ Professional Expected Damages

Cost Estimation

Enter the Project Useful Life:

0

Select Hazard Type...

Riverine Flood

Coastal A Flood

Coastal V Flood

Coastal Unknown Flood

Hurricane Wind

Hurricane Safe Room

Tornado Safe Room

Wildfire

Drought

Landslide

Seismic

Dam/Levee Break

Extreme Temperature

Infrastructure Failure

Severe Storm

Tsunami

Volcano

Winter Storm

Uncategorized

Figure 12: Hazards available for Non-Residential Building using the Modeled Damages methodology

[Home](#)
[Project Summary](#)

Project Configuration

Project Title

Enter Project Title

Property Location

Enter a location

OR

Latitude

Latitude

5-digit Zip Code

Longitude

Longitude

Select State

Select County

Property Structure Type

Critical Facility Building

Hazard Type

Select Hazard Type...

Mitigation Action Type

Select Mitigation Action Type...

Property Title

Enter Property Title

Frequency and Damage Relationship based on:

☒ Modeled Damages
 ☐ Historical Damages
 ☐ Professional Expected Damages

Cost Estimation

Enter the Project Useful Life:

0

Select Hazard Type...

- Riverine Flood
- Coastal A Flood
- Coastal V Flood
- Coastal Unknown Flood
- Hurricane Wind
- Hurricane Safe Room
- Tornado Safe Room
- Wildfire
- Drought
- Landslide
- Seismic
- Dam/Levee Break
- Extreme Temperature
- Infrastructure Failure
- Severe Storm
- Tsunami
- Volcano
- Winter Storm
- Uncategorized

Figure 13: Hazards available for Critical Facility using Modeled Damages methodology

[Home](#)
[Project Summary](#)

Project Configuration

Project Title

Enter Project Title

Property Location

Enter a location

OR

Latitude

Longitude

Latitude

Longitude

5-digit Zip Code

Select State

Select County

Property Structure Type

Utilities

Hazard Type

Drought

Mitigation Action Type

Aquifer Storage and Recovery

Property Title

Aquifer Storage and Recovery @

Frequency and Damage Relationship based on:

☒ Modeled Damages
 ☐ Historical Damages
 ☐ Professional Expected Damages

Cost Estimation

Enter the Project Useful Life:

0

Select Hazard Type...

- Riverine Flood
- Coastal A Flood
- Coastal V Flood
- Coastal Unknown Flood
- Hurricane Wind
- Hurricane Safe Room
- Tornado Safe Room
- Wildfire
- Drought**
- Landslide
- Seismic
- Dam/Levee Break
- Extreme Temperature
- Infrastructure Failure
- Severe Storm
- Tsunami
- Volcano
- Winter Storm
- Uncategorized

Figure 14: Hazards available for Utilities using the Modeled Damages methodology

Damage Frequency Assessment vs. Historic/Professional Estimated Damages

What used to be known as the “Damage Frequency Assessment” module is now separated into two methodologies based on the type of data you have: “Historic Damages” or “Professional Estimated Damages.” These approaches are available for every hazard option. If your analysis is based on historic damage amounts and years with either known or unknown recurrence intervals, then you would use the “Historical Damages” method. If your analysis is based on damage estimates from a licensed professional with known recurrence intervals, then you would use the “Professional Estimated Damages” approach.

If you have both historic and expected damages, for example from a flooding event with known flood depths but no associated claims data, you should use the Historical Damages option and then enter the expected damages along with the appropriate recurrence interval(s) in the table with the historic damages.

The Historic Damages and Professional Expected Damages approaches are the only options available for the Roads/Bridges and Utilities property types (with the exception of drought projects). See Figure 14 and Figure 15. For residential structures, non-residential structures, and critical facilities, you have to manually switch to these approaches. You would also use one of these approaches for projects mitigating hazards such as landslides, tsunamis, or winter storms.

Home

Project Summary

Project Configuration

Project Title

Enter Project Title

Property Location

Enter a location

OR

Latitude

Longitude

Latitude

Longitude

5-digit Zip Code

Select State

Select County

Property Structure Type

Roads & Bridges

Hazard Type

Select Hazard Type...

Mitigation Action Type

Select Mitigation Action Type...

Property Title

Enter Property Title

Frequency and Damage Relationship based on:

Modeled Damages

☒

Historical Damages

☐

Professional Expected Damages

Cost Estimation

Enter the Project Useful Life:

0

Select Hazard Type...

Riverine Flood

Coastal A Flood

Coastal V Flood

Coastal Unknown Flood

Hurricane Wind

Hurricane Safe Room

Tornado Safe Room

Wildfire

Drought

Landslide

Seismic

Dam/Levee Break

Extreme Temperature

Infrastructure Failure

Severe Storm

Tsunami

Volcano

Winter Storm

Uncategorized

Figure 15: Hazards available for Roads & Bridges using Historical Damages methodology

Home

Project Summary

Project Configuration

Project Title

Enter Project Title

Property Location

Enter a location

OR

Latitude

Longitude

Latitude

Longitude

5-digit Zip Code

Select State

Select County

Utilities

Hazard Type

Select Hazard Type...

Mitigation Action Type

Select Mitigation Action Type...

Property Title

Enter Property Title

Frequency and Damage Relationship based on:

Modeled Damages

☒ Historical Damages

☐ Professional Expected Damages

Cost Estimation

Enter the Project Useful Life:

0

Select Hazard Type...

Riverine Flood

Coastal A Flood

Coastal V Flood

Coastal Unknown Flood

Hurricane Wind

Hurricane Safe Room

Tornado Safe Room

Wildfire

Drought

Landslide

Seismic

Dam/Levee Break

Extreme Temperature

Infrastructure Failure

Severe Storm

Tsunami

Volcano

Winter Storm

Uncategorized

Figure 16: Hazards available for Utilities using Historical Damages methodology

Navigating the Tool

Adding a Project

Once you have opened the Toolkit window, you'll see the Home screen. Click on "Add Project" to begin your analysis as shown in Figure 16.




Figure 17: Adding a project

Enter your project title in the first field of the Project Configuration screen as shown in Figure 17. This will be your title for all the mitigation actions/structures in your project. Then enter your structure information.

Project Configuration

Project Title

Enter Project Title

Property Location

Enter a location

OR

Latitude

Latitude

Longitude

Longitude

5-digit Zip Code

Select State

Select County

Property Structure Type

Select Structure Type...

Hazard Type

Select Hazard Type...

Mitigation Action Type

Select Mitigation Action Type...

Property Title

Enter Property Title

Frequency and Damage Relationship based on:

Modeled Damages

Historical Damages

Professional Expected Damages

Use Property Location?

Yes

Use Decimal Degrees?

Yes

Figure 18: Project Configuration screen

Once you have entered your structure information and project costs, click “Next” to continue to the hazard analysis screen, as shown in Figure 18.

Property Location	400 C St SW, Washington, DC 20024, USA	Use Property Location? <input checked="" type="checkbox"/> Yes
OR		
	Latitude 38.8858710	Longitude -77.0177620
	20024	District of C... Washington
Property Structure Type	Residential Building	
Hazard Type	Riverine Flood	
Mitigation Action Type	Acquisition	
Property Title	Acquisition @ 400 C St SW, Washington, DC 20024, USA	
Frequency and Damage Relationship based on:	<input checked="" type="radio"/> Modeled Damages <input type="radio"/> Historical Damages <input type="radio"/> Professional Expected Damages	

Cost Estimation		
Enter the Project Useful Life:	100	<div>Use Default? <input type="checkbox"/> Yes</div>
Enter the Initial Project Costs (\$):	300,000.00	
Enter the Number of Maintenance Years:	100	
Enter the Annual Maintenance Costs (\$):	0.00	
Total Mitigation Project Cost (\$)	300,000	

Next

Figure 19: Remainder of Project Configuration screen

Adding Comments

To add a comment for any input field, click the comment box to the right of the field as shown in Figure 19. Then enter your comment in the comment box and click “Save” to close the window.

500

14

55,555

Building Information

Select Building Type:

Does the Building have a Basement?

Does the Building have an Accessible Entrance?

Add justification for Building has basement

See "Elevation Certificate.pdf"

Save

Standard Benefits - Building

Select Damage Curve:

USACE Generic

Enter Building Size (sq.ft):

2,400

Building Replacement Value (\$/sq.ft):

100

Use Default? Yes

Demolition Threshold (%):

50

Use Default? Yes

Expected Annual Losses due to Building Damages Before Mitigation (\$):

4,163

Figure 20: Adding comments

If you want to enter your own input for a default value, for example the Building Replacement Value, click on the “Use Default?” toggle to switch it to “No.” See Figure 20. This will also unlock the comment box.

Standard Benefits - Building

Select Damage Curve:

USACE Generic

Enter Building Size (sq.ft):

2,400

Building Replacement Value (\$/sq.ft):

100

Use Default? ☒ Yes

Demolition Threshold (%):

50

Use Default? ☒ Yes

Expected Annual Losses due to Building Damages Before Mitigation (\$):

4,163

Expected Annual Losses due to Building Damages after Mitigation (\$):

0.00

Expected Annual Benefits - Building (\$):

4,163

Figure 21: Using non-default values

Be sure to enter a comment for all non-default values noting where the supporting documentation for that value can be found in the project application. See Figure 21.

Standard Benefits - Bui

Select Damage Curve:

Enter Building Size (sq.ft):

Building Replacement Value

Demolition Threshold (%):

Expected Annual Losses due to Building Damages Before Mitigation (\$):

Expected Annual Losses due to Building Damages after Mitigation (\$):

Expected Annual Benefits - Building (\$):

View Damage Curve

Add justification for Building Replacement Value

Local BRV is \$150/square foot. See BRV.pdf in project application.

Save

0.00
0.00
0

Figure 22: Using the comment box

The comment box will turn blue to indicate that you have entered a comment. See Figure 22.

Building Information

Select Building Type:

Two or More Stories

Does the Building have a Basement?

☐ Yes

Does the Building have an Active NFIP Policy?

☒ No

Standard Benefits - Building

Select Damage Curve:

USACE Generic

Enter Building Size (sq.ft):

2,400

Building Replacement Value (\$/sq.ft):

200.00

Demolition Threshold (%):

50

Expected Annual Losses due to Building Damages Before Mitigation (\$):

8,325

Expected Annual Losses due to Building Damages after Mitigation (\$):

0.00

Expected Annual Benefits - Building (\$):

8,325

Use Default?

☒ No

Use Default?

☐ Yes

Figure 23: Comment boxes highlighted

Accessing the Help Content

To access the help content, click the white “i” button on any card as shown in Figure 23. This will open a sidebar window with the help content. What information appears is dependent on the page of the Toolkit you’re on and the card you click on.

Project Configuration

Project Title

Enter Project Title

Property Location

Enter a location

OR

Latitude

Latitude

Longitude

Longitude

5-digit Zip Code

Select State

Select County

Property Structure Type

Select Structure Type...

Hazard Type

Select Hazard Type...

Mitigation Action Type

Select Mitigation Action Type...

Property Title

Enter Property Title

Frequency and Damage Relationship based on:

Modeled Damages

Historical Damages

Professional Expected Damages

Use Property Location?

Yes

Use Decimal Degrees?

Yes

Figure 24: Help content icon

Figure 24 shows the help content that appears for the Project Configuration screen.

PROJECT CONFIGURATION

The purpose of this section is to:

- Name your project
- Establish the location of the project area or the structure being mitigated
- Direct the BCA Tool which module your intend to use

For additional assistance, see the Help content for the individual inputs.

Project Title

Property Location

Property Structure Type

Hazard Type

Mitigation Action Type

Frequency and Damage Relationship

COST ESTIMATION

Figure 25: Help content window for Project Configuration screen

The Help content that appears on the Hazard Analysis screens differs from the Project Configuration screen. Clicking on the Help icons in these cards will open different sections of the Help content.

Building Information

Select Building Type:

Two or More Stories

Does the Building have a Basement?

Yes

Does the Building have an Active NFIP Policy?

No

Standard Benefits - Building

Select Damage Curve:

USACE Generic

Enter Building Size (sq.ft):

2,400

Building Replacement Value (\$/sq.ft):

200.00

Use Default? No

Demolition Threshold (%):

50

Use Default? Yes

Expected Annual Losses due to Building Damages Before Mitigation (\$):

8,325

Expected Annual Losses due to Building Damages after Mitigation (\$):

0.00

Expected Annual Benefits - Building (\$):

8,325

Figure 26: Help content icons in Building Information and Standard Benefits - Building cards

The Help content for “Hazard Probability Parameters – Flood” opens when you click on the Help icon on that card. You can access the rest of the help content for that by clicking on the carrots on the right-hand side of the toolbar to expand or collapse the sections, as shown in Figure 26.

RIVERINE FLOOD MODULE OVERVIEW	×
HAZARD PROBABILITY PARAMETERS – FLOOD This section establishes the before-mitigation flood risk for the structure being mitigated. For project types like elevations and flood barriers, there is an additional input required about the elevation of these activities that are used to calculate the after-mitigation damages and losses.	×
Lowest Floor Elevation (ft)	×
Streambed Elevation (ft)	×
How many feet is the lowest floor being raised?	×
Elevation for the Top of Barrier or Floodproofing	×
Recurrence Interval: Water Surface Elevation (ft) and Discharge (cfs)	×
Recurrence Interval: Elevation (ft) (after mitigation) and Discharge (cfs) (after mitigation)	×
BUILDING INFORMATION	×
STANDARD BENEFITS - BUILDING	×
STANDARD BENEFITS - CONTENTS	×

Figure 27: Help content for "Hazard Probability Parameters – Flood" with expand/collapse carrots highlighted

Adding a Structure to a Project

To add another structure or mitigation action to your project, click on the “Add Mitigation Action” button on the Project Summary screen as shown in Figure 27. This will open the Project Configuration screen for a new structure within that project.







Benefit-Cost Analysis									
Project Name: Sample Project									
<div><div> Home</div><div> Add Mitigation Action</div><div> Delete Mitigation Actions</div><div> View Report</div></div>									
SELECT	MAP MARKER	MITIGATION TITLE	PROPERTY TYPE	HAZARD	BENEFITS (B)	COSTS (C)	BCR (B/C)	COPY	
<input checked="" type="checkbox"/>	1	Acquisition @ 400 C St SW, Washington, DC 20024, USA		Riverine Flood	\$ 323,923	\$ 300,000	1.08		
Totals					\$ 323,923	\$ 300,000	1.08		

Figure 28: Adding a structure to a project

Copying a Structure

To copy a structure within a project, click the “Copy” button to the right of the structure BCR, as shown in Figure 28.



Benefit-Cost Analysis								
Project Name: Sample Project								
<div>HomeAdd Mitigation ActionDelete Mitigation ActionsView Report</div>								
SELECT	MAP MARKER	MITIGATION TITLE	PROPERTY TYPE	HAZARD	BENEFITS (B)	COSTS (C)	BCR (B/C)	COPY
<input checked="" type="checkbox"/>	1	Acquisition @ 400 C St SW, Washington, DC 20024, USA		Riverine Flood	\$ 323,923	\$ 300,000	1.08	
Totals					\$ 323,923	\$ 300,000	1.08	

Figure 29: Copying a structure

Deleting a Structure

To delete a structure within a project, select the checkbox next to the structure you want to delete and click the “Delete Mitigation Actions” button, as shown in Figure 29. Make sure that you select only the structure(s) you want to delete.

Benefit-Cost Analysis
Project Name: Sample Project

Home

Add Mitigation Action

Delete Mitigation Actions

View Report

SELECT	MAP MARKER	MITIGATION TITLE	PROPERTY TYPE	HAZARD	BENEFITS (B)	COSTS (C)	BCR (B/C)	COPY
<input checked="" type="checkbox"/>	1	Acquisition @ 400 C St SW, Washington, DC 20024, USA		Riverine Flood	\$ 323,923	\$ 300,000	1.08	
Totals					\$ 323,923	\$ 300,000	1.08	

Figure 30: Deleting a structure

Viewing a Report

To view the BCA report, select all the structures you want to include in your report and click “View Report” as shown in Figure 30.

Benefit-Cost Analysis									
Project Name: Sample Project									
<div><div> Home</div><div> Add Mitigation Action</div><div> Delete Mitigation Actions</div><div> View Report</div></div>									
SELECT	MAP MARKER	MITIGATION TITLE	PROPERTY TYPE	HAZARD	BENEFITS (B)	COSTS (C)	BCR (B/C)	COPY	
<input checked="" type="checkbox"/>	1	Acquisition @ 400 C St SW, Washington, DC 20024, USA		Riverine Flood	\$ 323,923	\$ 300,000	1.08		
Totals					\$ 323,923	\$ 300,000	1.08		

Figure 31: Viewing a report

Printing/Saving the Report

To print or save the report, click “Print Report” at the top of the View Report screen as shown in Figure 31.




Figure 32: Printing the report



To save your report as a PDF, select “Print to PDF” and click “Print.”

Note: The Print Report function does not always work properly when using Excel for Mac. This issue will be addressed in the next release of the Toolkit. As a workaround, users may take a screenshot(s) of the Project Report page.




Figure 33: Printing the report

Exporting a Project

To export a project, select only the project(s) you want to export, then click “Export Projects” as shown in Figure 33.


<div><div><div><div>+</div><div>Add Project</div></div><div><div>🗑</div><div>Delete Projects</div></div><div><div>→</div><div>Export Projects</div></div></div></div>						
SELECT	PROJECT TITLE	COUNTY, STATE	BENEFITS (B)	COSTS (C)	BCR (B/C)	COPY
<input checked="" type="checkbox"/>	Sample Project	Washington, DC	\$ 323,923	\$ 300,000	1.08	
Totals			\$ 323,923	\$ 300,000	1.08	

Figure 34: Exporting a project

This will open a download screen in Internet Explorer (see Figure 34). Click Save and select the location where the zip file should be saved, renaming the file if you prefer. You do not need to open the zip file.

Note: The Export Projects function does not always work when using Excel for Mac. This issue will be addressed in the next release of the Toolkit. As a workaround, users may take a screenshot(s) of the Project Report page.




Figure 35: Export zip file screen

Importing a Project

To import a project, click the “Import Projects” button as shown in Figure 35.

+ Add Project

🗑 Delete Projects

➡ Export Projects

SELECT

☑

PROJECT TITLE

COUNTY, STATE

BENEFITS (B)

COSTS (C)

BCR (B/C)

COPY

☑

Sample Project

Washington, DC

\$ 323,923

\$ 300,000

1.08

📄

Totals

\$ 323,923

\$ 300,000


1.08

← Import Projects

🗨 View Case Studies

Figure 36: Importing a project

This will open a side-bar window as seen in Figure 36. Click “Select File” to choose your zip file to import.



FEMA

Benefit-Cost Calculator

v6.0.0 (Build 20190402.2227)

+ Add Project

🗑 Delete Projects

➡ Export Projects

SELECT

☑

PROJECT TITLE

COUNTY, STATE

BENEFITS (B)

COSTS (C)

☑

Sample Project

Washington, DC

\$ 323,923

\$ 300,000

Totals

\$ 323,923

\$ 300,000

Import Projects

Select the project file to perform the project merge.

Project File:

Select File

Import

Cancel

Figure 37: Import project window

Select the zip file you want to import and click “Open” as shown in Figure 37.




Figure 38: Import project selection on Windows machine

Click “Import” to import the file as seen in Figure 38.




Figure 39: Importing a project - last step

The project will appear in the Home page with the date and time you imported it, as shown in Figure 39.






+ Add Project  Delete Projects  Export Projects						
SELECT	PROJECT TITLE	COUNTY, STATE	BENEFITS (B)	COSTS (C)	BCR (B/C)	COPY
<input checked="" type="checkbox"/>	Sample Project	Washington, DC	\$ 323,923	\$ 300,000	1.08	
<input checked="" type="checkbox"/>	Riverine Flood Project [Imported on 4/26/2019 @ 11:42:55]	St Louis County, MO	\$ 548,419	\$ 275,000	1.99	
Totals			\$ 323,923	\$ 300,000	1.08	

Figure 40: Imported project on Home screen

The imported file will be locked so that you cannot make any changes to it, as seen in Figure 40. To make edits to an imported project, you must copy the project.



FEMA

Benefit-Cost Calculator
v6.0.0 (Build 20190722.2208)

[Home](#) [Project Summary](#)

Project Configuration

Project Title

Test Project [Imported on 7/23/2019 @ 9:58:8]

Property Location

400 C St SW, Washington, DC 20024, USA

OR

Latitude

38.8858710

Longitude

-77.0177620

20024

District of Colum... ▾

Washington ▾

Property Structure Type

Non-Residential Building ▾

Hazard Type

Tornado Safe Room ▾

Mitigation Action Type

Community ▾

Property Title

Community @ 400 C St SW, Washington, DC 20024, USA

Frequency and Damage Relationship based on:

☒ Modeled Damages

☐ Historical Damages

☐ Professional Expected Damages

Use Property Location?

☐ Yes

Use Decimal Degrees?

☐ Yes

Figure 41: Locked imported project

To copy a project, click the “Copy Project” button to the right of the project overview information on the Home screen, as shown in Figure 41.

+ Add Project Delete Projects Export Projects						
SELECT	PROJECT TITLE	COUNTY, STATE	BENEFITS (B)	COSTS (C)	BCR (B/C)	COPY
<input checked="" type="checkbox"/>	Sample Project	Washington, DC	\$ 323,923	\$ 300,000	1.08	
<input checked="" type="checkbox"/>	Riverine Flood Project [Imported on 4/26/2019 @ 11:42:55]	St Louis County, MO	\$ 548,419	\$ 275,000	1.99	
Totals			\$ 323,923	\$ 300,000	1.08	

Figure 42: Copying a project

The copied project will have the date and time you copied it. If you copied an imported project, the copy will now be unlocked.








+ Add Project  Delete Projects  Export Projects						
SELECT 	PROJECT TITLE	COUNTY, STATE	BENEFITS (B)	COSTS (C)	BCR (B/C)	COPY 
	Sample Project	Washington, DC	\$ 323,923	\$ 300,000	1.08	
	Riverine Flood Project [Imported on 4/26/2019 @ 11:42:55]	St Louis County, MO	\$ 548,419	\$ 275,000	1.99	
	Riverine Flood Project [Imported on 4/26/2019 @ 11:42:55] [Copied on 4/26/2019 @ 11:43:29]	St Louis County, MO	\$ 548,419	\$ 275,000	1.99	
Totals			\$ 1,420,761	\$ 850,000	1.67	

Figure 43: Copied project on Home screen

You can edit the project title for copied projects in the Project Configuration screen for any structure.

Project Configuration

Project Title

Riverine Flood Project [Imported on 4/26/2019 @ 11:42:55]

Property Location

9340 White Ave, Brentwood, MO 63144, USA

Use Property Location?☒ Yes

OR

Latitude

38.6208272

Longitude

-90.3587467

Use Decimal Degrees?☐ Yes

63144

Missouri

St Louis Co...

Property Structure Type

Residential Building

Hazard Type

Riverine Flood

Mitigation Action Type

Acquisition

Property Title

Acquisition @ 9340 White Ave, Brentwood, MO 63144, US/

Frequency and Damage Relationship based on:

☒ Modeled Damages

☐ Historical Damages

☐ Professional Expected Damages

Figure 44: Editing the project title of a copied project

Deleting a Project

To delete a project, select the checkbox next to the project you want to delete and then click “Delete Projects,” Make sure to select **only** the project(s) you want to delete, as shown in Figure 44. The tool will ask you if you are sure you want to delete the project and all associated data, as shown in Figure 44. If you want to delete the project, click “Yes” to permanently delete the project.







+ Add Project  Delete Projects  Export Projects						
SELECT <input type="checkbox"/>	PROJECT TITLE	COUNTY, STATE	BENEFITS (B)	COSTS (C)	BCR (B/C)	COPY
<input checked="" type="checkbox"/>	Tornado Safe Room	Douglas, KS	\$ 27,472	\$ 5,000	5.49	
<input type="checkbox"/>	Hurricane Safe Room	Dade, FL	\$ 2,126,475	\$ 100,000	21.26	
<input type="checkbox"/>	Wind Retrofit	Washington, DC	\$ 320	\$ 75,000	0.00	
<input type="checkbox"/>	Seismic Non-Structural Test	CA	\$ 42,922	\$ 20,000	2.15	
Totals			\$ 27,472	\$ 5,000	5.49	

Figure 45: Deleting a project

File Management

Saving the File

While the Toolkit calculations are performed within the add-in window, the data and projects themselves are stored within the Excel file. In order to save your projects once you have performed your BCA, you must:

1. Click Finish on the Hazard Analysis screen.
2. Close the add-in window.
3. Save the Excel file. You can save the Excel file the same way you would any other Microsoft Office file, by using “Ctrl+S,” by navigating to File -> Save, or by using the AutoSave function in later versions of Excel. It is important to save **early** and **often** so as not to lose any data.

Saving in Excel Online

To save your work in Excel Online, you must do the following:

1. Click Finish on the Hazard Analysis screen.
2. Close the add-in window.
3. Save a copy of the Excel file to your local machine by clicking File, Save As, Download a Copy, and choosing the “Open with Microsoft Excel” option.
4. When the file opens in Excel, go to File, Save As, and save a copy to your local machine.
5. To reopen the file, click “Upload a Workbook” in Excel Online and navigate to the file on your local machine.

Organizing Projects

Because the Toolkit now works in Excel, you no longer have to store all your projects in the same database. Instead, you can now define your own file organization system. For example, you could save all BCAs from a specific disaster, subapplicant, or application cycle in its own file.

To do this, you would go to “Save As,” name the file based on your preferred naming conventions (e.g. “DR-0000_Application_BCAs” or “FMA19_BCAs”), save the file in your preferred location, and then delete all unrelated projects from the file.

Version Control

The Toolkit automatically updates to the latest version as long as you are connected to the Internet when you reopen it. Because of this, the Toolkit implements version control when exporting and importing completed projects to ensure that your BCRs do not change if a standard value is updated.

Once you export a project, the inputs in your project will be locked so that you can no longer change any values. All imported projects will also be locked to prevent changes. To make any changes to your BCA, you will have to copy the original project. You can then edit the copied project. The original project will stay locked.

Frequently Asked Questions

Getting Started

1. I'm having trouble installing/opening the Toolkit. Where can I get help?

The BCA Helpline can provide assistance with installation and launch issues. Email the Helpline at bchelp@fema.dhs.gov or call 1-855-540-6744.

2. Why can't I open the add-in in another Excel spreadsheet?

The add-in only works when opened in the [FEMA-approved template](#). This ensures that no unauthorized changes can be made to the Toolkit or the calculations.

3. How can I learn more about FEMA's Benefit-Cost Analysis (BCA) process?

To learn more about FEMA's Benefit-Cost Analysis requirement, its methodology, available resources, training materials, or technical assistance, please visit www.fema.gov/benefit-cost-analysis. Updated training materials and BCA reference guide will also be posted here once they are finalized.

For specific questions about doing a BCA, please email the BCA Helpline at bchelp@fema.dhs.gov or call 1-855-540-6744.

4. Why is my project grayed out when I open it?

If you exported your project or imported a project from someone else, your project will be grayed out next time you open it. This is intentional—because the Toolkit can automatically update values when you connect to the Internet, locking the project when it is exported or imported ensures that someone sees the same BCA results regardless of what version they use or when they open the project.

To edit the project, hit the “Copy Project” button on the home screen. You can now edit the copied project, including the project title, as needed.

General

5. What should I do if I'm unfamiliar with a term or concept?

If you come across an unfamiliar term or concept, the first place you should look is the Help content. The Help content is always signified by a white "i" in a blue circle. Clicking on this will prompt the tool to open a sidebar displaying the help content for that page. The help content is designed to be dynamic, so that different information appears depending on what page of the tool you're on and which card you click on.

If you have questions about how to perform an analysis, you can refer either to the training materials available on www.fema.gov/benefit-cost-analysis or by contacting FEMA's Benefit-Cost Helpline at bchelp@fema.dhs.gov.

6. Can I still use v.5.3.0 if I want?

Yes, you can continue to use v.5.3.0 to develop and submit BCAs for HMA projects through the end of the 2019 application cycle for PDM and FMA. FEMA will no longer update, fix, or support v.5.3.0, however, so we recommend that you transition to the new version sooner rather than later.

The sole exception to this is for seismic structural and non-structural retrofits. FEMA is currently updating its seismic methodology, so users should continue to use v.5.3.0 for all seismic retrofit projects until the new methodology has been incorporated into v.6.0. You can, however, use v.6.0 for seismic infrastructure projects.

7. Can I use the BCA Toolkit v.6.0 for a FEMA Public Assistance mitigation project?

Yes. FEMA uses the same BCA methodology and software for both its Hazard Mitigation Assistance and Public Assistance programs.

8. Where is the Damage Frequency Assessment module?

The Damage Frequency Assessment (DFA) module is no longer a separate module within the Toolkit. Instead, it is now an analysis option contained within every hazard option. To use what was formerly known as the DFA, select either "Historical Damages" or "Professional Estimated Damages" as the damage frequency relationship option. If your analysis is based on past damages with known event years, select "Historical Damages." If your analysis is based on probable damages with known recurrence intervals as estimated by a licensed professional, select "Professional Estimated Damages."

9. Can I upload my documentation into the Toolkit?

No, Version 6.0 does not allow the user to upload or attach documents within the Toolkit. Any documentation or supporting information for your BCA should be uploaded into the project application intake system along with your project application. Use the comment box with each data field to refer the BCA reviewer to the appropriate document in your project application.

10. Can I change a default value?

Yes. With a few exceptions, such as project effectiveness for wildfire mitigation, you can change all default values in the Toolkit. Simply click on the Default Value toggle button to switch it from “yes” to “no.” This will unlock the input field so you can now type in your own value. You MUST make sure to provide a comment in the comment box, however, stating where you got that value and where the reviewer can find it in your application or supporting documentation (e.g. “See Project_Budget.pdf for project costs”).

11. Can I import projects from v.5.3.0 into v.6.0?

No, there is no way to export projects from v.5.3.0 to v.6.0. We therefore recommend that you not delete v.5.3.0 and that you make sure to save reports from past projects so that you can re-enter the data as necessary.

12. How do I update the Toolkit?

You don’t need to! As long as your computer is connected to the Internet, the Toolkit will update to the most recent version when you re-open it. If you are not sure if you have the current version, you can check the release notes available at [this link](#). We publish release notes every time we make any substantial changes or updates to the Toolkit so that users know what has changed.

13. Why doesn't my BCR change when I change an input?

Try clicking out of the input box. Sometimes the Toolkit does not update the BCR when you type in a new value. Clicking in another input box or elsewhere on the screen should cause the tool to re-calculate your BCR. If that still doesn't work, try clicking "Finish" at the bottom of the page and then reopening that structure. You should now see the correct BCR.

14. What should I do if I find an error in the Toolkit?

If you find a calculation error, spelling error, or other type of mistake in the Toolkit, please send an email with a screenshot of the error to the Benefit-Cost Helpline at bchelpine@fema.dhs.gov. The helpline staff will log the error and contact FEMA and the software developers so that they can fix it.

Structure, Hazard, Mitigation Action, and Damage Frequency Relationship Options

15. Why are some hazards grayed out?

Version 6.0 has integrated the behind-the-scenes business logic in v.5.3.0 so that the hazard options that appear depend on a) the structure type selected for analysis and b) the analysis methodology. Instead of clicking through multiple screens to select the correct structure and analysis type, the Toolkit will only let users select certain combinations based on possible analysis options. For example, selecting “Roads & Bridges” as the structure type will make the analysis methodology default to “Historical Damages,” as these types of infrastructure projects always use service loss as the basis of analysis. When selecting a residential structure, the Toolkit defaults to modeled damages, although the user can switch to historical/professional estimated damages depending on the data they have.

16. How do I select a hazard that’s grayed out?

To select a hazard that’s grayed out, switch the damage-frequency relationship button from “Modeled Damages” to either “Historical Damages” or “Professional Estimated Damages” depending on the data you have. For example, if you would like to do a BCA for a landslide soil stabilization project on a residential structure, you would first select “residential” for structure type and then switch to “professional estimated damages.” This will allow you to select “landslide” as the hazard and then “soil stabilization” as the mitigation action.

17. How do I do a BCA for a generator in v.6.0?

The primary hazard that generators mitigate is loss of power. Power outages can be caused by multiple hazards, such as flooding or high winds. In order to do a BCA for a generator project, the recommended approach is to select the structure type, most likely “Critical Facility” or “Utilities,” and then select “Infrastructure Failure” as the hazard. If you selected “Critical Facility” for your structure, you will first need to switch the damage frequency relationship to either “Historical Damages” or “Professional Estimated Damages” in order to select “Infrastructure Failure” as the hazard. Whether you select Historical or Professional Estimated Damages depends on the type of data you have to document your damages. The mitigation action will then be “other.”

18. How do I do a hurricane wind retrofit or a hurricane safe room for a critical facility?

To do a BCA for a hurricane safe room for a critical facility, you have to select “Non-Residential Building” as the structure type and then select “Hurricane Safe Room” as the hazard. This is because the benefits are not based on loss of service of the facility but loss of life of the people inside the safe room.

When conducting a BCA for a hurricane wind retrofit of a critical facility, there are two options for how to analyze the benefits. Which one is appropriate depends on whether the project will reduce physical damages to the building or loss of service. If the project primarily reduces physical damages and/or loss of function resulting from the physical damages, then the user should select Non-Residential Building for the structure type and use the modeled

damages approach. If the project's loss of service reduction is primarily based on reduced service down time instead of improved building performance, then the user should select "Critical Facility" as the structure type and use the historical or professional expected damages approach.

Reports

19. How do I save or print my report?

To save or print your BCA report, select the structures you want included in your project on the "Project Summary" screen and then click "View Report" to open the report. At the top of the screen, click "Print Report." This will open up a print window. From here, you can either select "Print to PDF" to save your report as a PDF or you can print the report directly.

20. Why can't I print the report or export projects on a Mac?

There is a known issue with v.6.0 that sometimes the "Print Report" and "Export Project" functions do not work when using Excel for Mac. The software developers are currently working on a fix for this issue, which will be included in the next update of the Toolkit.

For now, Mac users can take screenshots of their reports and share the Excel spreadsheet file via email or document upload as workarounds for these issues.

Appendix A: Installation Instructions

Excel desktop (Non-FEMA machines)

1. Download the .xlsx file at [this link](#) and open it.
2. In the Insert tab, in the Add-ins section, click on My Add-ins.
3. With My Add-ins selected, click on the Office Store button.
4. In the Office Store, search for “FEMA Benefit-Cost Analysis Calculator.” Click Add.
5. You should now see the FEMA BCA V6.0 icon in the upper righthand ribbon.
6. To launch the Toolkit, click on the FEMA BCA button. A sidebar will open.
7. Click Open Calculator to begin your BCA.
8. The add-in window will open and take you to the Home screen. From here you can start a new project by clicking Add Project.
9. To save your work, click “Finish” on the second screen, and save the Excel file, renaming it if desired.

Excel desktop (FEMA machines)

1. Download the .xlsx file at [this link](#) and open it.
2. In the Insert tab, in the Add-ins section, click on My Add-ins.
3. With Admin Managed selected, click on FEMA Benefit-Cost Analysis.
4. You should now see the FEMA BCA V6.0 icon in the upper righthand ribbon.
5. To launch the Toolkit, click on the FEMA BCA V6.0 button. A sidebar will open.
6. Click Open Calculator to begin your BCA.
7. The add-in window will open and take you to the Home screen. From here you can start a new project by clicking Add Project.
8. To save your work, click “Finish” on the second screen, close add-in window, and save the Excel file, renaming it if desired.

Excel Online

If using a FEMA machine, you will need to use Firefox as your browser.

Important Note: You must make sure to save a copy of the file to your local machine once you have closed the add-in window. You may do this by clicking File, Save As, Download a Copy, and choosing the “Open with Microsoft Excel” option. Once the file opens, click File, Save As, and save a copy to your local machine.

1. Download the .xlsx and .zip files (the first two files) at [this link](#) and save them to your machine. You will need to unzip the .zip file.
2. If you don't already have one, set up an Office 365 account at <https://www.office.com/>. This is free to set up.
3. Once logged in, open Excel Online by clicking on the Excel icon under Apps.
4. Open the file BCA_Toolkit_6.xlsx in Excel Online by clicking Upload a Workbook or Upload and Open.




Figure 46: Excel Online main screen (may look different depending on Office 365 account type and browser)

5. In the Insert tab, click Office Add-ins.




Figure 47: BCA Toolkit 6.0 launch screen in Excel Online

6. Click on the Upload My Add-in link.




Figure 48: Office Add-ins window in Excel Online

7. Browse to where the unzipped .xml file was saved, select it, and click open.
8. You should now see the FEMA BCA V.6.0 button in the top righthand side.




Figure 49: BCA Toolkit 6.0 button in Excel Online

9. To launch the Toolkit, click on the FEMA BCA button. A sidebar will open.




Figure 50: BCA Toolkit 6.0 sidebar in Excel Online

10. Click “Open Calculator.” You may be asked if you want to allow your browser to open another window. Click Allow.




Figure 51: Pop-up window asking if you want to allow your browser to open another window

11. The add-in window will open and take you to the Home screen. From here you can start a new project by clicking Add Project.