

- 1. Detail shown is for abutments with pavement sawcut. Modify drawing and provide closed cell foam as required for the abutment type being used.
- 2. Edge of keeper block shall not extend beyond the line of the back of wingwall. The curtain wall and keeper block can be combined for the design of the seismic restraint. If the width is still not sufficient, use intermediate abutment keeper blocks.



HORIZONTAL SECTION ABUTMENT W/ U-WINGWALL

BRIDGE SEAT DETAILS

DATE OF ISSUE JUNE 2013

DRAWING NUMBER

3.7.3