## **NOTES:**

(See Dwg. No. 3.1.6, Part II of this Bridge Manual, for Notes 1 thru 8 to be included on Construction Drawings).

- 9. PRE-BED PRECAST COMPONENT WITH NON-SHRINK GROUT WITH THICKNESS MORE THAN SHIM STACK.
- 10a. PRIOR TO PLACEMENT OF CAP FILL CMP VOIDS WITH 4000 PSI, \( \frac{3}{4} \) IN., 610 CEMENT CONCRETE (Omit Note 10a for Stub Abutments)
- 10b. FILL CMP VOIDS WITH 4000 PSI,  $\frac{3}{4}$  IN., 610 CEMENT CONCRETE.
- 11. AFTER SETTING PRECAST CAP FILL REMAINDER OF CMP VOID WITH CONCRETE (Only use this note with Dwg. No. 1.1.3, Part II of this Bridge Manual)

## **NOTES:**

- 1. Where piles are used, see pier footing details.
- 2. Increase concrete cover by 1" where concrete is exposed to salt water.



CONSTRUCTION NOTES

PRECAST ABUTMENTS

DATE OF ISSUE JUNE 2013

DRAWING NUMBER

1.1.5