


OAKSON, INC.

 Wastewater Product Sales

Installer's Checklist for the Perc-Rite Drip Dispersal System

Installation Sequence:

- Rope off dispersal area to protect from traffic and/or compaction
- Set septic tank and pump tank
- Place hydraulic unit and control panel
- Install Cool-Guide and pump
- Install float tree
- Dig ditches for supply and return lines and install
- Install drip tubing
- Install loops (flex tubing) connecting ends of drip tubing
- Dry fit pressure lines, field manifolds and air release valves
- Glue all fittings and place air release valve boxes-**do not final fit air release valves at this point**
- Connect electrical components (and phone line to control panel if applicable)
- Provide clean water in tank (above "Drip Enable" float) for start-up
- Remove air release Flush all laterals through air release valves
- Final fit air release valves
- Pressure check all fittings and lines
- Find any leaks and repair
- Backfill once lines and laterals are determined to have no leaks.
Backfilling is to be controlled to prevent damage to the pipes or fittings.
Do not compress soil over the field
- Grade, seed and mulch site

Oakson, Inc. is committed to excellence. Please feel free to contact us with questions regarding any issue.

February 07