

## NOTES:

- 1. ALL CONCRETE ABOVE SLAB SHALL BE POURED IN ALTERNATING SECTIONS WITH NOT LESS THAN 3 DAYS BETWEEN POURS.
- 2. DO NOT CARRY LONGITUDINAL BARS THROUGH THE PARAFFIN JOINTS. END THE REINFORCEMENT 2" CLEAR OF JOINT.
- 3. JOINT SHALL BE SQUARE TO FACE OF CURB (or coping).

## PARAFFIN JOINT DETAILS

SCALE:  $\frac{3}{4}$ " = 1'-0"

## NOTES:

- 1. Modify the details shown in this section as required to show the correct shape, wearing surface and support beams.
- 2. Paraffin joints shall be spaced preferably between 20' and 25'. A minimum of 15' may be used, if necessary. Paraffin joints for sidewalks and safety curbs with S3—TL4 rail shall be located using the above spacing, provided that the location of the joint falls approximately at the center of the railing panel. The location of the joints shall be dimensioned on the Construction Drawings.



CF BARRIERS AND NOTES

PARAFFIN JOINT DETAILS

DATE OF ISSUE JUNE 2013

DRAWING NUMBER

9.9.3