


WINGWALL ELEVATION

SCALE: $\frac{1}{2}$ " = 1'-0"



* Denotes dimensions
that vary for gravity wall.

SECTION 3

SCALE: $\frac{1}{2}$ " = 1'-0"



LRFD BRIDGE
MANUAL, PART II

CONSTRUCTION JOINT DETAILS

WINGWALL DETAILS

DATE OF ISSUE
JUNE 2013

DRAWING NUMBER

3.2.6