



## LIMITS OF PREFORMED FILLER

SCALE: 1" = 1'-0"



LRFD BRIDGE  
MANUAL, PART II

## PREFORMED FILLER IN EXPANSION JOINTS

WINGWALL DETAILS

DATE OF ISSUE  
JUNE 2013

DRAWING NUMBER

**3.2.9**