





BOTTOM FLANGE LONGITUDINAL STIFFENER TERMINUS DETAIL NOT TO SCALE



BOTTOM FLANGE LONGITUDINAL STIFFENER/PIER CROSS FRAME INTERFACE NOT TO SCALE

NOTES:

1. Refer to AASHTO-LRFD for additional information regarding size and location of the transverse stiffener and it's connection to the longitudinal stiffener. Show location of transverse stiffener on framing plan.
2. Longitudinal stiffeners are typically only required for wider than normal box girders and the bearing stiffener details shown on Dwg. No. 5.3.9 will need to be modified to accommodate this detail.



LRFD BRIDGE
MANUAL, PART II

LONGITUDINAL STIFFENER DETAILS STEEL BOX GIRDER

DATE OF ISSUE
JUNE 2013

DRAWING NUMBER

5.3.11