



Burn Building Fuel Load Restrictions (Straw & Food Service Pallets Only)

1. Based on years of experience, best practices have been developed to limit the maximum amount of straw to be used per room per evolution. Programs such as Recruit and Advanced/Structural Firefighting Practices are free to determine the amount of straw to be used during the phases/evolutions of burns provided they do not exceed the maximum.
2. Smudges will be determined as needed by the Interior Safety Officer (IS) with a maximum of one bail per floor.

DFS-Stow:

Basement:

- LL1 – 2 bales maximum
- LL2 – 2 bales maximum
- LL3 – 2 bales maximum

1st Floor:

- 101 – 1 bale maximum
- 102 – 1 bale maximum
- 103 – 1 bale maximum
- 104 – 2 bales maximum
- 105 – 1 bale maximum
- 106 – 1 bale maximum

Burn Manger only-All Rooms

- 3 pallets maximum
- 1 bale maximum

3rd Floor:

- 4 bales maximum

2nd Floor:

- 201 – 1 bale maximum
- 202 – 2 bales maximum
- 203 – 2 bales maximum
- 204 – 1 bale maximum
- 205 – 2 bales maximum

DFS-Bridgewater:

Burn Manger only-All Rooms:

- 3 pallets maximum
- 1 bale maximum

DFS-Springfield:

1st Floor:

- 100 - 1 bale maximum
- 101 - 3/4 to 1 bale maximum
- 102 - 1/4 bale maximum
- 103 - 1 bale maximum
- 104 - 1/4 bale maximum
- 105 - 1/2 bale maximum
- 107 - 1/2 to 3/4 bale maximum
- 108 - **NO BURNING IN THIS ROOM** (Electrical Panel in this space)

2nd Floor:

- 201 – 3/4 bale maximum
- 202 – 3/4 bale maximum
- 203 – 3/4 bale maximum
- 204 – 1/4 bale maximum
- 205 – 1/2 bale maximum
- 207 – 3/4 bale maximum

3rd Floor:

- 301 - 1 bale maximum

Burn Manger only-All Rooms:

- 3 pallets maximum
- 1 bale maximum