




▶ Audi e-tron

from 2019



Legend

Airbag	Rein-force-ment	SRS control unit	High voltage battery
Stored gas inflator	Auto-matic roll bar	12 V Battery	High voltage -cable/ -component
Seatbelt preten-sioner	Cylinder	Fuel Tank	High voltage emergency disconnect

e-tron

This document is a subject to the copyright of AUDI AG, Ingolstadt. Any duplication, distribution, storage, communication, broadcast and reproduction or transmission of the contents without written approval from AUDI AG is prohibited.





► Audi e-tron


from 2019

Characteristic features

The Audi e-tron can be identified by the characteristic body design (only electric drive variant), the charging socket and the e-tron logo.







e-tron

The e-tron logo at the rear and side can optionally be deselected





Vehicle immobilization

1. Push “P“-Button on gear lever
2. Apply parking brake





Switch off ignition

Press START-STOP button without depressing brake pedal



Warning: When pressing the START-STOP button and depressing the brake pedal at the same time, the vehicle switch to “ready to drive“!





► Audi e-tron

from 2019

Deactivation of High Voltage System


⚠ **The High Voltage System is automatically deactivated during accidents in which the airbag(s) deployed.**


For all other cases, deactivate the High Voltage System as follows

Alternative 1 – Emergency disconnect in the vehicle front end accessible,

open the motor compartment hood

1. Locate the emergency disconnect ➔ on the left side next to the plenum panel
2. Pull out red flap from emergency disconnect
3. Pull out black plug while pressing the red tab









Alternative 2- Emergency disconnect fuse in trunk

1. Remove the cargo floor
2. Remove fuse box cover
3. Identify emergency fuse disconnection tab and pull out the tab











▶ Audi e-tron


from 2019

Disconnect 12 V battery

The 12 V battery is located in the vehicle front end under a cover, next to the plenum panel.

The 12 V negative battery cable is connected to the chassis suspension strut, see picture 1.
Unscrew the negative battery cable from the chassis suspension strut, see picture 2.


picture 1


picture 2

The 12 V battery can be accessed when the cover and control boxes located on the top of the battery are removed, see picture 3-5.


picture 3


picture 4


picture 5

Disconnect charging cable

Vehicle connected to charging station:

1. Unlock vehicle via remote control or central locking switch
2. Disconnect charging cable

If needed, refer to additional steps in this rescue sheet



