



INTERMEDIATE ABUTMENT KEEPER BLOCK

SCALE: 1" = 1'-0"

NOTES:

1. Intermediate keeper blocks are only used when the standard seismic restraints are insufficient. Avoid locating an intermediate keeper block in a utility bay. The sides of the intermediate keeper block are to be parallel with the adjacent beams.
2. Detail shown is for abutments with pavement sawcut. Modify drawing and provide closed cell foam as required for the abutment type used.



LRFD BRIDGE
MANUAL, PART II

INTERMEDIATE KEEPER BLOCK – PLAN SECTION

BRIDGE SEAT DETAILS

DATE OF ISSUE
JUNE 2013

DRAWING NUMBER

3.7.7