

## Source Water Assessment Program (SWAP) Report For Fairlane Mobile Home Park

Table 1: Public Water System (PWS) Information

#### What is SWAP?

The Source Water Assessment Program (SWAP), established under the federal Safe Drinking Water Act, requires every state to:

- ? Inventory land uses within the recharge areas of all public water supply sources;
- ? Assess the susceptibility of drinking water sources to contamination from these land uses; and
- ? Publicize the results to provide support for improved protection.

# SWAP and Water Quality

Susceptibility of a drinking water source does *not* imply poor water quality. Actual water quality is best reflected by the results of regular water tests.

Water suppliers protect drinking water by monitoring for more than 100 chemicals, treating water supplies, and using source protection measures to ensure that safe water is delivered to the tap.

Prepared by the Massachusetts Department of Environmental Protection, Bureau of Resource Protection, Drinking Water Program

> Date Prepared: June 10, 2001

Well #1	2162003-01G	210	520	Moderate		
Well Name	Source ID#	Zone I (in feet)	IWPA (in feet)	Source Susceptibility		
Phone Number	(978) 772-2143					
Local Contact	Rene Lafleur					
PWS ID Number	2162003					
City/Town	Lunenburg, MA					
PWS Address	1990 Massachusetts Avenue					
PWS NAME	Fairlane Mobile Home Park					

### Introduction

We are all concerned about the quality of the water we drink. Drinking water wells may be threatened by many potential contaminant sources, including septic systems, road salting, and improper disposal of hazardous materials. Citizens and local officials can work together to better protect these drinking water sources.

#### Purpose of this report:

This report is a planning tool to support local and state efforts to improve water supply protection. By identifying land uses within water supply protection areas that may be potential contaminant sources, the assessment helps focus protection efforts on appropriate best management practices (BMPs) and drinking water source protection measures. Department of Environmental Protection (DEP) staff are available to provide information about funding and other resources that may be available to your community.

#### This report includes:

- 1. Description of the Water System
- 2. Discussion of Land Uses within Protection Areas
- 3. Recommendations for Protection
- 4. Attachments, including a Map of the Protection Areas

## 1. Description of the Water System

The well for Fairlane Mobile Home Park is located besides one of the trailers. The well has a Zone I of 210 feet and an Interim Wellhead Protection Area (IWPA) of 520 feet. The well is located in an aquifer with a high vulnerability to contamination due to the absence of hydrogeologic barriers that can prevent contaminant migration. Please refer to the attached map of the Zone I and IWPA. The well serving the facility has no treatment at this time. For current information on monitoring results and treatment, and for a copy of the most recent Consumer Confidence Report, please contact the Public Water System contact person listed above in Table 1.

## What is a Protection Area?

A well's water supply protection area is the land around the well where protection activities should be focused. Each well has a Zone I protective radius and an Interim Wellhead Protection Area (I WPA).

• The Zone I is the area that should be owned or controlled by the water supplier and limited to water supply activities.

• **The IWPA** is the larger area that is likely to contribute water to the well.

In many instances the IWPA does not include the entire land area that could contribute water to the well. Therefore, the well may be susceptible to contamination from activities outside of the IWPA that are not identified in this report.

#### What is Susceptibility?

Susceptibility is a measure of a well's potential to become contaminated due to land uses and activities within the Zone I and Interim Wellhead Protection Area (I WPA).

### 2. Discussion of Land Uses in the Protection Areas

There are a number of land uses and activities within the drinking water supply protection areas that are potential sources of contamination.

Key issues include:

- 1. Inappropriate Activities in Zone I;
- 2. Septic systems;
- 3. An Aboveground Storage Tank (AST) with heating oil;
- 4. Transportation Corridor.

The overall ranking of susceptibility to contamination for the well is Moderate, based on the presence of low and moderate threat land use or activity in the IWPA, as seen in Table 2.

1. Zone Is – Currently, the well does not meet DEP's restrictions, which only allow water supply related activities in Zone Is. The facility's Zone I contains buildings, an access road, and parking area. A resident has a vegetable garden right next to the well. The public water supplier does not own and/or control all land encompassed by the Zone I. Please note that systems not meeting DEP Zone I requirements must get DEP approval and address Zone I issues prior to increasing water use or modifying systems.

#### **Recommendations:**

- ✓ Remove all non-water supply activities from the Zone I to comply with DEP's Zone I requirements.
- $\checkmark$  Do not use or store pesticides, fertilizers or road salt within the Zone I.
- ✓ If the facility intends to continue utilizing the structures, road, and parking areas in the Zone I, use BMPs and restrict activities that could pose a threat to the water supply.
- 2. Septic systems The septic systems are located within the IWPA of the well. If a septic system fails or is not properly maintained it could be a potential source of microbial contamination. Improper disposal of household hazardous chemicals to septic systems is a potential source of contamination to the water supply. Recommendations:
- ✓ Staff and residents should be instructed on the proper disposal of spent household chemicals. Include custodial staff, groundskeepers, and certified operator.

## Table 2: Table of Activities within the Water Supply Protection Areas

Potential Contaminant Sources	Zone I	IWPA	Threat	Comments
Parking spaces, driveways & roads	Yes	Yes	Moderate	Limit road salt usage and provide drainage away from wells
Septic System	No	Yes	Moderate	See septic system brochure
Fuel Storage Above Ground	Yes	Yes	Moderate	Heating oil for residential use
Transportation Corridor	No	Yes	Moderate	Salt, accidents
Vegetable garden	Yes	Yes	Moderate	Fertilizer use

\* -For more information on Contaminants of Concern associated with individual facility types and land uses please see the SWAP Draft Land Use / Associated Contaminants Matrix on DEP's website - www.state.ma.us/dep/brp/dws/.

#### Glossary

**Zone I:** The area closest to a well; a 100 to 400 foot radius proportional to the well's pumping rate. To determine your Zone I radius, refer to the attached map.

IWPA: A 400 foot to ½ mile radius around a public water supply well proportional to its pumping rate; the area DEP recommends for protection in the absence of a defined Zone II. To determine I WPA ra dius, refer to the attached map.

**Zone II:** The primary recharge area defined by a hydrogeologic study.

Aquifer: An underground water-bearing layer of permeable material that will yield water in a usable quantity to a well.

Hydrogeologic Barrier: An underground layer of impermeable material that resists penetration by water.

**Recharge Area:** The surface area that contributes water to a well.

- ✓ Septic system components should be located, inspected, and maintained on a regular basis. Refer to the appendices for more information regarding septic systems.
- **3.** Aboveground Storage Tank (AST) with heating oil There is an AST located within the protection area of he well. If improperly managed, ASTs can be a potential contaminant source due to leaks or spills of the chemicals they store.

#### **Recommendations:**

- ✓ Aboveground storage tanks in your IWPA should be located on an impermeable surface, and also contained in an area large enough to hold the complete liquid volume, should a spill occur.
- ✓ Upgrade all oil/hazardous material storage tanks to incorporate proper containment and safety practices. Any modifications to the AST must be accomplished in a manner consistent with Massachusetts's plumbing, building, and fire code requirements. Consult with the local fire department for any additional local code requirements regarding ASTs.
- Transportation corridor A portion of Route 2A is located within the IWPA of the well. Transportation corridors can be a potential source of contamination from road salt or accidental leaks or spills.
  Becommendation

#### Recommendation

✓ Work with the local fire department to ensure that they include your IWPA in the Emergency Response Planning.

Implementing the following recommendations will reduce the system's susceptibility to contamination.

## 3. Protection Recommendations

Implementing protection measures and best management practices (BMPs) will reduce the well's susceptibility to contamination. Fairlane Mobile Home Park should review and adopt the key recommendations above and the following:




Figure 1: Example of how a well could become contaminated by different land uses and activities.

#### Zone I:

- ✓ Keep non-water supply activities out of the Zone I.
- ✓ Consider well relocation if Zone I threats cannot be mitigated.
- ✓ If it's not feasible to purchase privately owned land within the Zone I at this time, consider a conservation restriction that would prohibit potentially threatening activities or a right of first refusal to purchase the property

#### **Training and Education:**

- ✓ Instruct residents not to dispose of household chemical waste into the septic system.
- ✓ Post drinking water protection area signs at key visibility locations.

#### **Facilities Management:**

- Implement standard operating procedures regarding proper storage, use and disposal of hazardous materials.
- ✓ Implement Best Management Practices (BMPs) for the use

#### For More Information:

Contact Josephine Yemoh-Ndi in DEP's Worcester Office at (508) 792-7650 x 5030 for more information and for assistance in improving current protection measures.

More information relating to drinking water and source protection is available on the Drinking Water Program web site at:

www.state.ma.us/dep/brp/dws/

#### Additional Documents:

To help with source protection efforts, more information is available by request or online at <u>www.state.ma.us/dep/brp/dws</u>, including:

- Water Supply Protection Guidance Materials such as model regulations, Best Management Practice information, and general water supply protection information.
- 2. MA DEP SWAP Strategy
- 3. Land Use Pollution Potential Matrix
- 4. Draft Land/Associated Contaminants Matrix

Copies of this assessment have been provided to the public water supplier, town boards, the town library and the local media. of fertilizer, herbicides and pesticides on facility property

#### **Planning:**

- ✓ Work with local officials in Lunenburg to include the facility IWPA in Aquifer Protection District Bylaws and to assist you in improving protection.
- ✓ Have a plan to address short-term water shortages and long-term water demands. Keep the phone number of a bottled water company readily available.
- ✓ Supplement the SWAP assessment with additional local information and incorporate it into water supply educational efforts. Use a potential contaminant threat inventory to assist in setting priorities, focusing inspections, and creating educational

#### **Funding:**

The Department's Wellhead Protection Grant Program provides funds to assist public water suppliers in addressing Wellhead protection through local projects. Protection recommendations discussed in this document may be eligible for funding under the "Wellhead Protection Grant Program". For additional information, please refer to the attached program fact sheet (Please note: each program year the Department posts a new Request for Response for the Grant program (RFR)).

These recommendations are only part of your ongoing local drinking water source protection. Citizens and community officials should use this SWAP report to spur discussion of local drinking water protection measures.

#### 4. Attachments

- Map of the Public Water Supply (PWS) Protection Area.
- Recommended Source Protection Measures Factsheet
- Your Septic System Brochure
- Pesticide Use Factsheet
- Wellhead Protection Grant Program Fact Sheet
- Source Protection Sign Order Form