



US Army Natick Soldier Research, Development & Engineering Center
The Science Behind the Warrior: Yesterday, Today and Tomorrow

Bi/Tricomponent Fiber Extrusion - A New Method to Produce High Performance Fibers

***Cleaner Technology and Energy Efficiency:
Structuring a Competitive Advantage***

April 5, 2007

Presented by:

Jean M. Herbert

Nanomaterials Science Team

US Army Natick Soldier RD&E Center

Natick, MA


jean.herbert@us.army.mil



High Performance Fiber COE at the Natick Soldier RDEC, Natick MA



The goal of NSRDEC's High Performance Fiber COE is to collaborate with academic and industrial partners to invent and transition fiber technology for use in woven and non-woven textiles for high performance, dual-use applications such as environmental/ballistic/CB protection and electrotexiles. NSRDEC has extensive fiber extrusion capabilities as well as state-of-the-art analytical capabilities such as Instron mechanical analysis, thermal analysis, transmission and scanning electron microscopy, nuclear magnetic resonance spectroscopy, liquid chromatography/mass spectrometry, and x-ray diffractometry.






Bi/Tri-Component Fiber Extruder Capabilities



Research-scale Bi/tri-component Fiber Extruder:

- Capacity – 1 to 6 pounds/hour
- $\frac{3}{4}$ Inch Diameter Single Screw
- Temperature Limit – 350°C
- Three Melt Pumps are Thermally Isolated
- Nitrogen Ports for Oxygen Sensitive Polymers
- Draw Speed – 500-2500 meters/min.



Hills, Inc.






















Bi-component Fiber Cross Sections



Bi-component spinning technology, which includes side-by-side, sheath/core, islands in the sea and segmented pie morphologies will lead to the development of lighter, reactive/responsive fabrics that will make the wearer safer, more comfortable and higher performing.

Bi-component fibers can also be used in applications besides clothing, to include soft shelters, parachutes, vehicles and numerous household fabrics.

The COE will utilize the expertise of NSRDEC engineers, chemists and textile technologists, along with fiber manufacturing experts in academia and industry to create and transition these new high performance fibers.


FAMILY	BICOMPONENT FIBERS					
	VARIANTS					
CORE & SHEATH	 50/50	 20/80	 ECCENTRIC	 TRILOBAL	 CONDUCTIVE	
SIDE BY SIDE	 50/50	 20/80	 MIXED VISCOSITY	 ABA MIXED VISCOSITIES	 TRILOBAL OR OTHERS	 CONDUCTIVE
TIPPED	 TRILOBAL	 CROSS				
MICRO-DENIER	 SEGMENTED PIE	 ISLANDS-IN-A-SEA	 STRIPED			
MIXED FIBERS	 COLORS	 DENIERS, COMPONENTS, CROSS-SECTIONS	 BICOMPONENT/HOMOFILAMENT			




Metal Core and Segmented Pie Cross-Sections



Increased heat or electrical transfer conductivity is possible



Metal Core Fibers could be used in electrotextile applications




Segmented pie and side-by-side configurations can be split to obtain greater surface area for reactive additives



Complex, Sheath-Core Cross-Sections




Increased material surface area is possible through tailoring fiber cross-section geometry






Islands-in-the-Sea (INS) Fibers




**Islands-in-the-Sea can be
used to make
thermoplastic nanofibers**





Transparent Fiber Composite Fabrication



**Light scattering may be prevented by refractive index matching
or using nano-scale reinforcing fibers**




Enhanced Transparencies for Ballistic Protection



Ballistic Limit

Monolithic polymers vs. Fiber-reinforced polymer composites





Physical/Mechanical Properties of Candidate Polymers



Polymer	Morphology	Density (g/cc)	Refractive Index (nD20)	Tensile Strength (MPa)	
				Fiber Form	Injection Molded
Polycarbonate	Amorphous	1.20	1.587	230	55-75
PMMA (Acrylic)	Amorphous	1.19	1.490	69	63
Semi-aromatic polyamide T5000	Amorphous	1.12	1.566	79	90
Cyclo-aliphatic polyamide CX7323	Semi-crystalline	1.02	1.516	189	60
Polypropylene	Semi-crystalline	0.90	1.490	400-800	25-40
Cyclo-aliphatic polyolefin 1020R	Amorphous	1.01	1.53	150	53
Cyclo-aliphatic polyolefin E48R	Amorphous	1.01	1.53	36	71



“Sheath/Core” (S/C) Fiber Cross-Section




**Polypropylene
Sheath/Core
(undrawn fiber)**







Composites from Fibers




**Bi-component fiber
transformed to
consolidated part**





Mechanical Testing - Composites

PP 1751/M3661
20/80 S/C
Fiber Composite






Mechanical Testing - Composites



Injection Molded Polypropylenes (isotropic)





Thermal/Mechanical Analysis

Differential Scanning Calorimeter (DSC)

- *TA Instruments Q100*
- Analyzes phase transitions such as crystallization, glass transition, curing, and certain chemical reactions
- Temperature range is -90°C to 725°C
- Features - modulated DSC, autosampler, and refrigerated cooling system.

Dynamic Mechanical Analyzer (DMA)

- *TA Instruments Q800*
- Measures the viscoelastic properties of solid samples
- Measures in cantilever, 3-point bend, shear, compression, and tension modes
- Temperature range is -150°C to 600°C.

Thermogravimetric Analyzer (TGA)

- *TA Instruments High-Resolution 2950*
- Temperature range – ambient temperature up to 1000°C
- Precisely measures the weight of a sample in relation to changes in temperature
- Determines degradation temperatures, absorbed moisture content, and solvent residues

Thermogravimetric Analyzer TMA

- *TA Instruments 2940*
- Measures the deformation of a sample under an applied force
- Analyzes coefficient of thermal expansion, softening, sintering, and glass transition temp
- Temperature range is -150°C to 1000°C

Dielectric Analyzer (DEA)

- *TA Instruments 2970*
- Measures the electrical response of a material in response to oscillating voltage
- Measures ionic conductivity, characterizes phase transitions involving dipolar groups
- Monitors curing reactions
- Temperature range is -150°C to 500°C.

Instron 5500R

Compression and Tensile Testing

Load cells

100N (22.5lbs)

1kN (225lbs)

10kN (2250lbs)

Assorted grips





Electron Microscopy




Scanning Electron Microscope (SEM)
Zeiss EVO60 SEM

3nm Resolution EDS Detector
Electron Beam Lithography
System (50nm resolution)

Transmission Electron **Microscope (TEM)**

Jeol 2010 TEM
3Å° Resolution
STEM mode
EDS detector
Gatan Image Filter (gif)
1M Pixel Digital Camera



Environmental Scanning **Electron Microscope (ESEM)**

Phillips XL30 ESEM
Wet, variable pressure SEM
imaging
Tensile stage
EDS detector
Hi-temp heating stage



Molecular/Atomic Structure




Nuclear Magnetic Resonance Spectrometer (NMR)

Bruker Avance 400MHz
High resolution liquids
High resolution solids and semi-solids
Diffusion in solids
Variable temperature control



X-Ray Diffractometer

Bruker D8 Discover
Wide angle and small angle
Crystal analysis software





Atomic Force Microscopes

Atomic Force Microscopes



Veeco Dimension III (originally built by Digital Instruments)

General imaging in contact mode
Electrochemical contact mode AFM
Scanning Tunneling Microscopy (STM)

Veeco Dimension IIIA (originally built by Digital Instruments)

General imaging in contact and non-contact (intermittent) mode
Imaging in liquid
Magnetic Force Microscopy
Lateral (Friction) Force Microscopy

Nanonics Imaging Ltd. MultiView 1000

General imaging in contact and non-contact (intermittent) mode
Imaging in liquid
Near-field Scanning Optical Microscopy (NSOM)
Nano-Thermal Analysis
Confocal Microscopy
Detection of change in refractive index of materials
Fluorescence Microscopy
3-D Lithography
Environmental Chamber with Vacuum pump and Cooling unit



Optical Analysis

Lasers

Continuum Nd:YAG Leopard picosecond laser
50ps pulse width, 1064, 532, and 355nm wavelengths

Continuum Optical Parametric Generator (pumped by Leopard)
Tunable from UV to red

Continuum Nd:YAG/Ruby Custom Nanosecond Laser
Nd:YAG: 10 ns pulse width
1064, 532 nm output
Ruby: 30 ns pulse width
694 nm output

Coherent Innova Ar/Kr laser
Continuous wave
Tunable output from UV to red wavelengths


Light Age Model 101 PAL Alexandrite Laser
50 ns pulse width
Tunable output 650 nm – 750 nm
Stokes and anti-stokes raman cells

LeCroy LC574A 4 GHz Oscilloscope

Spectrophometers

Perkin Elmer Lambda 900 UV/Vis/NIR spectrophometer
UV-VIS-NIR (186nm – 3300nm)
Liquid/solid samples -
transmission absorbance and reflectance spectra
60mm and 150mm integrating spheres
Optical bench accessory for system customization

Ocean Optics UV and visible fiber optic spectrometers





High Performance Fiber COE Potential Collaborative Projects



NSRDEC is Seeking Partners for:

Novel Bi/Tri-component Fiber Development

- ✦ **Optical Fibers**
- ✦ **Electronic Fibers**
- ✦ **High Strength Fibers**
- ✦ **Flame Retardant Fibers**
- ✦ **Reactive Fibers**

Prototype Woven Textile Production

- ✦ **Production of Small Swatches**
- ✦ **Performance Specification Testing**

Prototype Non-woven Textile Production

- ✦ **Small Sample Production**
- ✦ **Performance Specification Testing**