



### NOTES:

1. METHACRYLATE CRACK SEALER SHALL BE APPLIED AFTER SIDEWALK OR SAFETY CURB/BARRIER CURING PERIOD IS COMPLETE AND IN ACCORDANCE WITH REQUIREMENTS OF MANUFACTURER AND THE STANDARD SPECIFICATIONS.
2. BEFORE SEALING, THE CONCRETE AT THE INTERFACE OF DECK AND CURB SHALL BE SWEEP CLEAN AND BLOWN OFF USING OIL FREE COMPRESSED AIR IMMEDIATELY PRIOR TO APPLYING THE SEALER.
3. APPLY  $\frac{1}{4}$ " HIGH BEAD OF SILICONE CAULKING COMPOUND ABOUT  $\frac{1}{4}$ " FROM THE FACE OF CURB.
4. METHACRYLATE SHALL THEN BE POURED INTO THE  $\frac{1}{4}$ " WIDE GAP BETWEEN THE FACE OF CURB AND THE BEAD OF CAULK.
5. CURB AT SIDEWALK SHOWN. SAFETY CURB IS SIMILAR.

## FACE OF CURB DETAILS

SCALE:  $1\frac{1}{2}$ " = 1'-0"